

XYLOFLOORING

URBAN HERRINGBONE LAMINATE (CHATEAU)

Thank you for your order

The complete fitting instructions are in the pack and should be **adhered to in full.**

The following is highlighted:

1. Use Underlay with a compression strength of minimum 100 kPa.
(XYLOTHERM fits this criteria, as it has a compression strength of 100kPa)
2. Always install expansion profiles in doorway
3. 8mm-10mm expansion in all areas with no kitchen units or islands installed directly on top on the laminate.
4. PVA short ends.
5. If fitting in Ladder or Mosaic style, these require full stick down with a flexible adhesive, they cannot be floated.