

# Wood Panel Installation Instructions

TUBA

TRUMPET MC

CORNET MM



- 1) Unplug all cables to unit, remove tubes. Place upside down on soft mat or towel.
- 2) Remove 4 screws, bottom cover should come off.
- 3) With wood panel face down (screw holes up), place bottom cover on top, aligning drilled holes with vent openings.
- 4) Insert screws into drilled holes. Tighten.
- 5) Do same to other side.
- 6) Bend bottom cover such that wood panels bend slightly inward. Very, very slightly.
- 7) Install bottom cover back onto unit, securing with 4 screws.
- 8) Flip upright, re-install tubes.

