

Mounting Wood Panels

Find a nice 1 x 4 board about 2 feet long. Cut 2 pieces to 10.5" length (0.75" x 3.5" x 10.5" finished size. Mahogany and Walnut work well with the color scheme. Sand all surfaces and edges; stain as desired.

Center the bottom cover side panel over a wood piece, mark the 4 screw hole locations. Use #6 x 1/2" sheet metal or pan head wood screws (M3.5 x 12). Repeat on other side.

