



Nissan 350Z DBW Pedal

Installation & Mounting in R Chassis with Outsider Garage RHD pedal adapter

1. Unhook cable from oem pedal assembly
2. Unbolt oem pedal assembly and remove
3. Install provided studs in firewall
4. Bolt 350Z Pedal assembly onto the billet pedal adapter with provided serrated flange bolts.
5. Slide completed pedal assembly over studs on firewall and tighten serrated flange nuts.

