



HOW TO HANG YOUR TERRAZZO WALL HOOKS

Your package includes three terrazzo wall hooks (screws attached) and three anchors. To get these beauties up, you'll also need to grab a drill and a hammer from your tool box.

STEP 1: "X" MARKS THE SPOT

Hold each hook up against the wall to decide where you want them. Once, you've found the perfect spot, mark with your pencil where the screw meets the wall.

STEP 2: TIME TO DRILL

Determine if you are drilling into a wall stud. If so, use a 3/32" drill bit to make a hole on your mark. Drill at 90-degree angle for best results. Then, screw your wall hook into the hole in the wall.

If you are not drilling into a stud, you'll need to use the anchor provided. Use a 1/4" drill bit to create the hole in your mark and carefully hammer the anchor until it is flush with the wall. Then, screw your wall hook straight into the anchor until it is flush against the wall. Voila! You're done.

Questions? We're here to help.

1.866.356.4284 // assistant@the-citizenry.com.

THE CITIZENRY

WWW.THE-CITIZENRY.COM