



HOW TO HANG YOUR SHELF MIRROR

Your package includes the mirror, a shelf, screws, and anchors. To hang this beauty, you will also need to grab a drill, hammer, and level.

STEP 1: HANG THE SHELF

First, hold the mirror and shelf where you'd like to hang it. Use a pencil to mark the top edges of the shelf.

Now, take the mirror and shelf down and set the mirror aside. Measure the distance from the top of the shelf to the mounting holes on the back. Then, go back to your first marks on the wall and measure down the same distance and make another pencil mark - these will be your final drill points.

Determine if you are drilling into a wall stud. If so, use a 3/32" drill bit to make a hole on your marks. Drill at a 90-degree angle for best results. Then, drill the provided screws into the holes. Remember to leave 1/4 of the screw exposed.

If you are not drilling into a stud, you'll need to use one of the anchors provided. Use a 1/4" drill bit to create the hole and carefully hammer the anchor into it until it is flush. Finally, drill the screw straight into the anchor. Leave 1/4 of the screw exposed.

Align the holes on the back of the shelf with the exposed screws and hang the shelf.

STEP 2: HANG THE MIRROR

If you purchased the semi-circle mirror, simply place the glass into the slot on the shelf, and voila, you're done! Please note the glass doesn't lean against the wall.

IF HANGING A FULL CIRCLE MIRROR, CONTINUE ON BACK

If you purchased the full circle mirror, place the glass in the slot of the hanging wood shelf and mark the top center. Take the mirror down and measure the distance from the top of the mirror to the mounting hole on the back. Then, go back to your first mark on the wall and measure down the same distance and make another pencil mark - this will be your final drill point for your mirror.

Determine if you are drilling into a wall stud. If so, use a 3/32" drill bit to make a hole on your mark. Drill at a 90-degree angle for best results. Then, drill the provided screw into the hole. Remember to leave 1/4 of the screw exposed.

If you are not drilling into a stud, you'll need to use one of the anchors provided. Use a 1/4" drill bit to create the hole and carefully hammer the anchor into it until it is flush. Finally, drill the screw straight into the anchor. Leave 1/4 of the screw exposed.

Align the hole on the back of the mirror with the exposed screw and simply hang the mirror on the wall. The mirror should fit perfectly in the slot of the shelf.



Questions? We're here to help.

1.866.356.4284 // assistant@the-citizenry.com

THE CITIZENRY

WWW.THE-CITIZENRY.COM