



LOCK-ON GRIP INSTRUCTIONS

THANK YOU FOR SELECTING NUKEPROOF LOCK-ON GRIPS.

With proper care and installation, it will give you trouble-free, enjoyable use. In order to maximise the safe enjoyment of this product, you should read and carefully follow the following installation instructions and warnings. Failure to do so could result in unexpected wear and or failure, possibly resulting injury. We recommend having your parts fitted by a qualified bicycle mechanic. Nukeproof assumes no responsibility for malfunction or injury due to faulty installation.

TOOLS REQUIRED:

- 2.5mm Allen Key

LOCK-ON GRIP INSTALLATION INSTRUCTIONS:

1. Make sure that the handlebar you intend to use has no sharp edges at the ends and that they are clean; (This ensures that the grip will not slip and rotate under load.)
2. When seated on the bike, slide the grip onto the bar with the clamp bolts facing you, until the edge of the bar is level with the end of the grip;
3. Rotate the grip so that the bolts are at the bottom edge of the bar;
4. Tighten the lock-on bolts to a maximum of 2Nm;
5. Repeat steps 2-4 for the second grip;
6. Insert the bar end plugs (if separate).

"LIMITED WARRANTY"

Nukeproof warrants this product to be free from defects in materials and workmanship for a two-year period from the date of original retail purchase. This warranty is extended only to the original owner of the product. Proof of purchase is required for any warranty service, so be sure to keep your receipt.

For full warranty terms and conditions visit <http://nukeproof.com/warranty/>