

X1 Stealth Bottom Bracket Conversion

There are 3 kinds of mounting brackets:

- Left mounting bracket:
 - L1: suitable to 68-83mm and BB92 bottom bracket
- Right mounting bracket:
 - R1: suitable to 68-83mm version
 - R2: suitable to BB92 version

There is 1 kind of hanger:

- H1: suitable to 68-83mm & BB92

There are 2 kinds of Freewheel 2.0 spacers:

- 6.3mm for BSA
- 11mm for PF

For Standard Freewheel

From \ To	68-83mm	BB92
68-83mm		<ul style="list-style-type: none"> ■ 68-83mm bottom bracket ■ R1 ■ Freewheel spacer
BB92	<ul style="list-style-type: none"> ■ BB92 bottom bracket ■ R2 ■ Remove freewheel spacer 	

For Freewheel 2.0

From \ To	68-83mm	BB92
68-83mm		<ul style="list-style-type: none"> ■ 68-83mm bottom bracket ■ R1 ■ 6.3mm FW spacers ■ Standard 11T sprocket ■ https://www.youtube.com/watch?v=KYIXQiNylde
BB92	<ul style="list-style-type: none"> ■ BB92 bottom bracket ■ R2 ■ 11mm FW spacers ■ Special 11T sprocket for X1 Stealth BB92 ■ https://www.youtube.com/watch?v=FbHlrZmylq4 	

