



Please read the instructions in full before assembly and note that all creases have been pre-folded.

Step 1. Take Panels, 1, 2 and 3 and pre-fold all the vertical side Flaps.

Step 2. Now Interlock all **A** Tabs on Panel 2 into the **A** Slots on Panels 1 and 3, creating a U shape. Push the Tabs until they are securely locked into the Slots.

Step 3. Take Panel 4 and interlock all **B** Tabs into the **B** Slots on Panels 1 and 3. Push the Tabs until they are securely locked into the Slots.

Step 4. Once all the **A** and **B** Tabs and Slots are interlocked, fold both the roof sections down, interlocking all **C** Tabs and Slots.

Step 6. Your Camper Van is now ready !

