

MirrorFlex Door Skins

Recommended Adhesives

Trowel on latex adhesives are recommended for adhering MirrorFlex Door Skins.

Brush-on or roller-on types, non-flammable, and water-based contact adhesives which are suitable for PVC, can also work well.

The following is meant as a guideline for adhesives that have been tested, and work well with MirrorFlex product:

- Titebond® Fast Grab FRP
- Loctite® PL Premium
- Loctite® PL Premium Fast Grab
- DAP® Weldwood FRP
- 3M™ 77 (spray on aerosol)