GEL BADGE INSTALL GUIDE

BEFORE INSTALLATION OF YOUR NEW GEL BADGES, PLEASE READ THROUGH THE INSTRUCTIONS CAREFULLY. PLEASE NOTE THAT ONCE THE GELS ARE REMOVED FROM THE BACKING PAPER, THEY ARE NON-REFUNDABLE.

- CLEAN THE CAR BADGES THOROUGHLY WITH AN ALCOHOL BASED WIPE WHICH SHOULD BE PROVIODED.
- USE A HAIR DRYER OR A WARM HEAT GUN TO GENTLY HEAT THE CAR BADGE.
- CAREFULLY REMOVE THE GEL BADGE FROM THE BACKING PAPER, USE THE HAIR DRYER/HEAT GUN TO GENTLY WARM THE GLUE ON THE BACK OF THE GEL BADGE.
- O4/ APPLY THE GEL BADGE TO THE CARS ORGINAL BADGE.
- PRESS DOWN HARD OVER THE WHOLE GEL BADGE FOR AT LEAST 1 MINUTE.
 HOLD DOWN THE BADGES WITH TAPE THEREAFTER FOR AT LEAST 2/3 HOURS.
- WHEN APPLYING ON THE WHEELS, USE HAIR DRYER/HEAT GUN TO WARM THE BADGES ONCE THEY ARE ON THE WHEELS, STICK DOWN WITH TAPE AND DO NOT DRIVE FOR AT LEAST 8 HOURS
- IF YOUR GEL BADGE STARTS TO PEEL, APPLY MORE HEAT TO WARM THE ADHESIVE AND PRESS DOWN FIRMLY.

IT IS HIGHLY RECOMMENDED THAT A CLEAN TOOTH PICK BE USED WHEN INSTALLING TINY INLAYS.

IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT US!