

STICKER FITTING INSTRUCTIONS

- 01** THOROUGHLY CLEAN THE SURFACE TO REMOVE ALL DIRT, GRIT AND GREASE. BE CAREFUL WITH WHAT PRODUCT YOU USED TO CLEAN THE GLASS, AS SOME WILL LEAVE A RESIDUE BEHIND THAT WILL PREVENT THE STICKER FROM ADHERING WELL. MOST ALCOHOL-BASED GLASS CLEANERS EVAPORATE SO WILL BE BEST FOR THIS.
- 02** PREPARE THE STICKER FOR APPLICATION BY FIRMLY RUBBING A CREDIT CARD/SQUEEGEE ACROSS THE LENGTH OF THE STICKER. THIS REMOVES ANY AIR BUBBLES THAT MAY HAVE FORMED AND MAKES THE STICKER CLING TO THE TRANSFER TAPE.
- 03** PEEL THE PAPER BACKING OFF THE STICKER. IF THE STICKER CLINGS TO THE BACKING, SLOWLY REPLACE THE PAPER BACKING AND REPEAT THE PREVIOUS STEP. TAKE EXTRA CARE WITH OUR CHROME AND GLITTER VINYLs WHEN DOING THIS.
- 04** PLACE THE STICKER ONTO THE SURFACE AND RUB IT IN PLACE FIRMLY WITH A CREDIT CARD/ SQUEEGEE ENSURING TO COVER THE WHOLE STICKER WHEN DOING THIS. FOR BEST RESULTS, WAIT A FEW MINUTES BEFORE MOVING TO THE NEXT STEP.
- 05** SLOWLY PEEL THE BACKING PAPER OFF AT AN ANGLE. BE CAREFUL NOT TO PULL THE STICKER OFF THE SURFACE. IF YOUR STICKER PULLS AWAY FROM THE SURFACE, REPEAT THE PREVIOUS STEP AGAIN UNTIL STUCK.