

# Altitude Tunnel Bag

## SSES12-16 / SSES12-24



### ***Altitude Tunnel Bag Installation Instructions:***

1. Determine where you want the bag to sit on your tunnel.
2. Clean the tunnel surface and remove the backing off the turf foam. Stick to the tunnel where the two parts of the bag make contact. Install at 60-degrees or warmer so the adhesive will stick properly.
3. Hang straps with buckles straight down at all four corners. Offset slightly to front and back for a tight fit.
4. Drill 3/16" holes and install one rivet per buckle.
5. Pull straps tight and tuck extra under the sides of the bag.

*Note: There are two methods you can use to secure your shovel scoop, either around the neck of the shovel or through it (as pictured).*



SLED SOLUTIONS

*For questions, please contact us at:  
586-215-6849  
[paul@sledsolutions.com](mailto:paul@sledsolutions.com)*