





PLEASE FOLLOW INSTRUCTIONS CAREFULLY!

Failure to follow instructions may result in ruined decal or poor adhesion.

Required Equipment:

- Squeegee (Included)
- Spray bottle with water and a drop or 2 of plain unscented dish soap
- Rubbing Alcohol & a clean microfiber towel
- Heat gun or hair dryer

Work on one section at a time. Perform all steps for each decal piece

<p>1. Clean decklid/tailgate with rubbing alcohol and dry with a microfiber towel.</p> <p style="text-align: center;"><i>Do not use window cleaner!</i> <i>Window cleaner will leave residue that prevents adhesion.</i></p>	
<p>2. Spray decklid/tailgate with soap/water solution.</p>	
<p>3. Remove white paper backing from decal. Spray soap/water solution onto the sticky side of the decal.</p>	
<p>4. Apply decal while decklid/tailgate and decal are wet. Decal should slide around freely for positioning. Respray if it does not.</p> <p>Use the pen marks on the transfer tape as guides to center your decal and align it with edges, badges, cameras etc.</p>	
<p>5. Thoroughly squeegee decal to remove all water and air. Wait 10-15 minutes before removing transfer tape!</p> <p><u>Low</u> heat will help remove any bubbles you may have missed</p>	