





**PLEASE FOLLOW INSTRUCTIONS CAREFULLY!**

*Failure to follow instructions may result in poor adhesion or ruined decal.*

**Required Equipment:**

- Squeegee (Included)
- Spray bottle with water and a drop or 2 of plain unscented dish soap
- Rubbing Alcohol & a clean microfiber towel
- Heat gun or hair dryer

<p>1. Clean taillight divider with rubbing alcohol and dry with a microfiber towel.</p> <p style="text-align: center;"><b><i>Do not use window cleaner!</i></b> <i>Window cleaner will leave residue that prevents adhesion.</i></p>	
<p>2. Spray taillight divider with soap/water solution.</p>	
<p>3. Remove white paper backing from decal. Spray soap/water solution onto the sticky side of the decal.</p>	
<p>4. Apply decal while taillight divider and decal are wet. Decal should slide around freely for positioning. Respray if it does not.</p> <p>Align the + with the trunk button and the top edge of the decal with the top edge of the taillight divider. Ensure sure all corners are even using pen mark guides.</p>	
<p>5. Thoroughly squeegee decal to remove all water and air. <u>Low</u> heat helps. <b>Wait 10-15 minutes before removing transfer tape!</b></p> <p>For multi-layer decals use <u>Low</u> heat and your finger to press around edges and details to push water/air out and bring out 3D effect.</p>	