






PLEASE FOLLOW INSTRUCTIONS CAREFULLY!

Failure to follow instructions may result in poor adhesion or ruined decal.

Required Equipment:

- Squeegee (Included)
- Spray bottle with water and a drop or 2 of plain unscented dish soap
- Rubbing Alcohol & a clean microfiber towel
- Heat gun or hair dryer

| | |
|--|---|
| <p>1. Clean window with rubbing alcohol and dry with a microfiber towel.</p> <p><i>Do not use window cleaner!</i> <i>Window cleaner will leave residue that prevents adhesion.</i></p> |  |
| <p>2. Spray window with soap/water solution.</p> |  |
| <p>3. Remove white paper backing from decal. Spray soap/water solution onto the sticky side of the decal.</p> |  |
| <p>4. Apply decal while window and decal are wet. Decal should slide around freely for positioning. Respray if it does not.</p> <p>Use guides drawn on transfer tape to center decal. You should have an equal gap around all edges.</p> |  |
| <p>5. Thoroughly squeegee decal to remove all water and air. <u>Low</u> heat will help adhere decal and dry water.</p> <p><i>Wait 10-15 minutes before removing transfer tape!</i></p> <p>Use <u>Low</u> heat and a wet finger and/or squeegee to remove any left over air/bubbles.</p> |  |