TM

Waterborne Polyurethane Premium Finish

For Floors, Cabinets and Interior Walls

- Fast Drying
- Low Odor
- Soap and Water Clean Up
- Hard, Abrasion Resistant Finish

STIR WELL BEFORE USING



1.0 gallon (approx. 3.8 liters)

Made in USA

SURE SHINE Polyurethane Premium Interior Finish
Sure Shine Premium Finish is specifically designed for finishing and protecting wood floors, cabinets, walls and other wood surfaces where a clear, durable, scuffresistant finish is desired. Its waterborne formulation is non-flammable, has little odor and resists yellowing. Once cured, Sure Shine is more durable than most
water or solvent-based clear finishes. Sure Shine's hard finish resists scuffing and abrasion and prevents discolorations from water and most household chemicals and cleaners. Sure Shine Premium Finish may be applied over previously stained or finished floors and woodwork. However, before coating an entire floor, test the performance of Sure Shine in a small, inconspicuous area such as a closet.

APPLICATION INSTRUCTIONS

Preparation: Wood surfaces should be dry and cleaned of all oils, grease, wax, dirt and dust. For best results wipe the entire area to be finished with a clean rag prior to application. If an oil-based stain has been applied to the wood, allow it to dry for at least three weeks then wipe it down with a clean cloth before applying Sure Shine.

Recommended Application Equipment: Use a synthetic bristle brush, foam brush or applicator pad to apply thin coats of Sure Shine. **Do not use a** roller or other types of applicators that apply thick coats! Sure Shine may be applied with an airless sprayer with back-brushing.

Walls, Cabinets and Trim

If applying to wood walls, cabinets or trim, first apply Llifeline Interior stain or Prelude Clear Wood Primer. Once the stain or primer has dried to the touch, the first coat of Sure Shine can be applied. Sure Shine should never be applied to green logs or wood with a moisture content in excess of 20%.

Application: Use a paint paddle to gently stir Sure Shine before using. Do not shake container or agitate as this creates foam that may result in air bubbles within the finish. Sure Shine is made to be used "as is." dilute Sure Shine with water or any other solvent. Do not tint.

Stir well before and during use. Apply thin coats of Sure Shine using smooth, even strokes in the same direction as the wood grain. Do one or two boards at a time ending at wood joints, walls or doorways to prevent lap marks.

After applying the first coat, allow it to dry to the touch (typically one to two hours) then lightly sand smooth using fine (180 grit or higher) sandpaper or buffing brush. Do not allow sanding procedure to build up excessive heat. **Do** not use steel woo!! We do not recommend sanding between subsequent coats. Although a minimum of three coats is recommended for new or worn wood floors, additional coats will add luster and depth to the finish.

Cleanup: Wash hands and tools with soap and warm water as soon as possible after use.

Drying Time: Although Sure Shine dries to the touch in approximately one to two hours, you should let the surface dry for about 12 hours before allowing light traffic. Avoid placing rugs or moving furniture over the finish for approximately one week. Sure Shine will reach full cure hardness within one

Estimated Coverage: One gallon of Sure Shine typically covers between 600 to 800 square feet. First coat coverage may be less on older, porous wood floors.

I IMITED WARRANTY

Perma-Chink Systems, Inc. warrants and represents that Perma-Chink Systems Family of Products will conform to the description and specifications previously set forth and be free from defects in material and workmanship when shipped to the buyer. EXCEPT WHEN HEREIN EXPRESSLY STATED, THERE ARE NO WARRANTIES, EXPRESSED OR IMPLIED, BY OPERATION OF LAW OR OTHERWISE, APPLICABLE TO THE PERMA-CHINK LOG HOME PRODUCT. PERMA-CHINK SYSTEMS EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR APARTICULAR PURPOSE.

