

Product Information

The problem:

Anyone who is unexpectedly caught in a rain shower knows how important impregnated textile or leather fabric (be it jacket, trousers or shoes) is. Even the outer material of waterproof membrane clothing soaks up water and causes unpleasant evaporative cooling. The body cools down and you have the feeling of being wet. In addition, the breathability of the membrane is greatly reduced.

The solution:



BIO F100[®]

Bio Reproofing
Spray



For the love of nature:

- Made from > 80 % natural raw materials
- Biodegradable according to standard: OECD 302(B)
- Fluorine free
- Free from harmful solvents
- Free of fragrances and dyes
- Bottle and label made from environmentally friendly recycled material
- Free from microplastics

Product advantages:

Highly effective and environmentally friendly impregnation

- Strong protection against moisture and dirt
- Highly effective protection against evaporative cooling
- Maintains the breathability of climate membranes (e.g. Gore-Tex, Sympatex)

Application areas:

Textile/leather fabrics, functional/ski clothing, shoes, tents, etc.



Application:

Wash textile with F100 Bio Functional Detergent before impregnation. Shake the bottle before use. Spray on the damp, clean fabric from a distance of 20-30 cm until the surface is completely wet. After 5 min working time, work into the textile with a sponge. Dry textile completely at room temperature. Drying time may vary depending on room temperature and humidity. Ideally treat with heat and observe the care instructions of the manufacturer. Heat treatment can be carried out e. g. by dryer, iron, hair dryer or sun exposure.

Note: When using a tumble dryer, dry the damp textile with a suitable program, e. g. gentle drying. When using an iron, dry textile only at room temperature and place a damp cloth between textile and iron. The ironing process should be done carefully at low speed. It is essential to follow the care instructions of the manufacturer. When using a hair dryer, keep a low temperature and a distance from the fabric of approx. 10- 15 cm.

The product's liquid content must be two thirds full. Returned consignments must be correctly stamped and proof of purchase (invoice) included.

