



Notes:

Showertray must be glued to floor.

Waterproofing membrane to overlap upstand.

Reinforcing mesh to be used with a liquid applied waterproofing membrane.

Waterproofing membrane to be applied as per manufacturers specifications.

Sealant to be compatible with membrane and shower tray e.g a neutral cure silicone such as Sikaflex MS

REV	DESCRIPTION	DATE	APPROVED
UNSPECIFIED LIMITS	+/- 0.1	ANG. +/- 0.5 DEG	
ALL DIMENSIONS IN MILLIMETERS.			

Clearlite Bathrooms

TITLE :  
Tile Installation

SCALE :

DRAWING No : TT3107

DRAWN: Hugh McIntyre

DATE : 31.05.2012

SHEET 1 OF 1