



# Turnoverball® Gooseneck Hitch Fit List

CHEVROLET  
GMC

GNRK	GNRM	GNRC	PICKUP TRUCK YEAR, MAKE AND MODEL
1020	1020	920	2020 Chevrolet & GMC 2500 & 3500 Trucks - Excludes Trucks with CarbonPro Bed
1016	1016	912	2016-2019 Chevrolet & GMC 2500 & 3500 Trucks
1012	1012	912	2011-2015 Chevrolet & GMC 2500 & 3500 Trucks
1019	1019	919	2019-2020 Chevrolet & GMC 1500 Trucks Excludes 2019 Chevrolet LD & GMC Limited & Trucks with CarbonPro Bed
1057	1057	959	2007-2018 Chevrolet & GMC 1500 Short Bed Trucks with Fully Boxed Frame 2019 Chevrolet LD & GMC Limited
1007	1007	959	2007-2018 Chevrolet & GMC 1500 Long Bed Trucks with Fully Boxed Frame
1067	1067	959	2001-2010 Chevrolet & GMC 2500 Heavy Duty Trucks 2007-2010 Chevrolet & GMC 3500 Trucks (With 1 bed cross member over the axle)
1062	1062	962	2001-2007 Chevrolet & GMC 3500 Trucks (With 2 bed cross members over the axle)
1059	1059	959	1999-2007 Chevrolet & GMC 1500 & 2500 Light Duty Trucks (Tube Frame changing to C-Channel before axle)
1050	1050	950	1988-1998 Chevrolet & GMC 1500, 2500 & 3500 Short Bed Trucks 1999-2000 Chevrolet & GMC 2500 & 3500 Short Bed Trucks (Full C-Channel Frame)
1000	1000	800	1988-1998 Chevrolet & GMC 1500, 2500 & 3500 Long Bed Trucks 1999-2000 Chevrolet & GMC 2500 & 3500 Long Bed Trucks (Full C-Channel Frame)
1400	1400		1973-1987 Chevrolet & GMC 1500, 2500, & 3500 Trucks (Requires Drilling into Frame)

FORD

1116	1117	816	2017-2019 Ford F250 & F350 Trucks 2017-2019 Ford F450 with Factory Installed Bed
1111	1111	800	2011-2016 Ford F250 & F350 Trucks 2011-2016 F450 with Factory Installed Bed
1115	1115	900	2015-2019 Ford F150 Trucks - Excludes F150 Raptor & 2019 F150 Limited
1104	1104	959	2004-2014 Ford F150 Trucks - Excludes 2004 F150 Heritage Edition
1108	1108	800	1999-2010 Ford F250 & F350 Trucks 2008-2010 F450 with Factory Installed Bed
1197	1197	800	1997-2003 Ford F150 without Air Bag Overloads & Light Duty F250 Trucks, & 2004 F150 Heritage Edition
1100	1100	800	1980-1998 Ford F250 & F350 Without Overload Springs - Excludes Light Duty F250
1110	1110	800	1980-1998 Ford F250 & F350 With Overload Springs (Requires Drilling into Frame)
1150	1150	800	1980-1996 Ford F150 Trucks

DODGE  
RAM

1320			2019 Ram 2500 & 3500 Trucks
1314			2013-2018 Ram 3500 Trucks
1384			2014-2018 Ram 2500 Trucks
1319	1319	800	2019-2020 Ram 1500 Gas Engine Trucks - Excludes 2019 Ram 1500 Classic
1309	1309	909	2009-2018 Dodge/Ram 1500 Trucks *Only GNXA4685 and RVK3500 with special post work with this hitch 2019 Ram 1500 Classic Trucks
1313	1313	900	2013 Ram 2500 Diesel Trucks 2010-2012 Ram 2500 & 3500 Diesel Trucks 2003-2009 Dodge 2500 & 3500 Trucks
1308	1308	907	2013 Ram 2500 Gas Engine Trucks 2013 Ram 2500 Mega-Cab Trucks 2010-2012 Ram 2500 & 3500 Gas Engine Trucks 2006-2012 Dodge/Ram 1500, 2500, & 3500 Mega-Cab Trucks
1316	1316	900	2002-2008 Dodge 1500 Trucks - Excludes Mega-Cab
1394	1394	900	1994-2002 Dodge 2500 & 3500 Trucks 1994-2001 Dodge 1500 Trucks
1300	1300		1973-1993 Dodge 1500, 2500, & 3500 Trucks (Requires Drilling into Frame)