

# RECEIVER HITCH APPLICATION GUIDE

ELEC	POS	OPTION 1				OPTION 2			OPTION 3	OPTION 4	* REQUIRES 4-FLAT WIRING		7-WAY HARDWIRE	PC	BRAKE CONTROL HARNESS	
		PC	T-ONE®	FN	IN	PC	OEM REP. HARN.	FN	IN	CIRCUIT PROTECTED HARDWIRE	GENERAL HARDWIRE	6-WAY ADAPTER			7-WAY ADAPTER	PC
<b>MERCURY (Continued)</b>																
C	PC3,4								119180							
A	PC3,4	E10	118351		10				119180	20252						
B	PC3,4	E9	118333	HG	10				119178	119130						
A	PC3,4	E4	118375		10				119180	20252						
B	PC3,4								119178	119130						
A	PC3,4	E7	118447		10				119180	20252	20320 20143	20321 20125 20144	20224			
C	PC3,4								119180							
A	PC3,4								119180	20252						
B	PC3,4								119178	119130						
A	PC3,4								119180	20252						
A	PC3,4								119180	20252						
B	PC1,2								119178	119130						
A	PC1,2	E5	118344		10				119180	20252						
A	PC1,2	E5	118344		10				119180	20252						
B	PC1,2								119178	119130						
B	SUV1,2								119178	119130	20320 20143	20321 20125 20144	20224			

A=2 wire system. No Converter required but a ModuLite® can be used.  
 B=3 wire system. Requires Converter but a ModuLite® can be used.  
 C=2 or 3 wire system determine at installation.  
 HG=T-One incorporates taillight converter.

CH1=Classic Hitch Class I 1-1/4"  
 CH2=Classic Hitch Class II 1-1/4"  
 CH3=Classic Hitch Class III 2"  
 CL1=Class I 1-1/4"  
 CL2=Class II 1-1/4"  
 CL3=Class III 2"  
 FH=Frame Hitch Class II 1-1/4"  
 MF=Max Frame Class III/IV 2"  
 PR=Professional Receiver Class III/IV 2"  
 PS2=Pro Series Class II 1-1/4"  
 SF=Sportframe Class I 1-1/4"

# T-ONE® CONNECTOR & OEM REPLACEMENT HARNESS APPLICATION NUMERICAL

Part No.	Years	Make/Model	PC	Install Time	Amp. Rating
118335	96-99	Chevrolet Express Van	E8	20	2.1,5
	96-99	GMC Savana Van		20	
118336	97-03	Acura CL Series	E5	5	2.1,5
	94-01	Acura Integra		5	
	01-06	Acura MDX		10	
	96-01	Acura RL Series		5	
	96-03	Acura TL Series		5	
	94-02	Honda Accord		5	
	93-97	Honda Civic Del Sol		5	
	97-06	Honda CR-V		10	
	03-04	Honda Element		10	
	95-04	Honda Odyssey		10	
	03-08	Honda Pilot		10	
	01-02	Honda Prelude		5	
96-99	Isuzu Oasis		10		
118337	93-96	Chevrolet Lumina APV Van	E7	20	7.5
	93-96	Oldsmobile Silhouette		20	
	93-96	Pontiac Trans Sport Van		20	
118338	87-95	Chevrolet Van, G-Series	E4	10	7.5
	87-95	GMC Van, G-Series		10	
118339	96-99	Acura SLX	E5	5	2.1,5
	92-02	Isuzu Trooper		5	
118341	96-02	Toyota 4Runner	E11	20	2.1,5
118343	92-94	Ford E-150 Econoline Van	E9	10	2.1,5
	92-94	Ford E-250 Econoline Van		10	
	92-94	Ford E-350 Econoline Van		10	
	01-03	Ford Escape		10	
	01-03	Mazda Tribute		10	

Part No.	Years	Make/Model	PC	Install Time	Amp. Rating
118344	97	Ford Aerostar Van	E5	10	7.5
	95-03	Ford E-150 Econoline Van		10	
	95-03	Ford E-250 Econoline Van		10	
	95-03	Ford E-350 Econoline Van		10	
	97-03	Ford Escort		10	
	00-03	Ford Excursion		10	
	97-03	Ford Expedition		10	
	01-03	Ford Explorer		10	
	02-03	Ford Explorer Sport Trac		10	
	97-03	Ford F-150 Light Duty		10	
	04	Ford F-150 Light Duty Heritage		10	
	00-03	Ford F-150 SuperCrew		10	
	00-03	Ford Focus Wagon		10	
	00-03	Ford Ranger Pickup		10	
	03-04	Lincoln Aviator		10	
98-03	Lincoln Navigator		10		
02-03	Mercury Mountaineer		10		
97-99	Mercury Tracer		10		
118345	92-94	Ford E-150 Econoline Van	E16	45	2.1,4,2
	92-94	Ford E-250 Econoline Van		45	
	92-94	Ford E-350 Econoline Van		45	
	01-03	Ford Escape		45	
	95-01	Ford Explorer		45	
	01-03	Mazda Tribute		45	
	97-01	Mercury Mountaineer		45	
118346	95-98	Ford Windstar	E9	20	2.1,5
118347	91-96	Buick Roadmaster	E3	10	7.5
	91-96	Chevrolet Caprice		10	
	94-96	Chevrolet Impala SS		10	
118348	93	Jeep Grand Cherokee	E17	45	2.1,4,2
	93	Jeep Grand Wagoneer		45	
118349	94-98	Jeep Grand Cherokee	E16	45	2.1,4,2
118350	92-96	Ford Bronco	E5	5	7.5