



**BRAKE CONTROL WIRING HARNESSES**

All vehicle specific brake control wiring harnesses are available in 1-Plug or 2-Plug styles.

1-Plug units are designed for brake controls manufactured with electrical wiring mounted on the back of the unit, otherwise known as a pigtail. Wiring harnesses must be spliced into the existing pigtail to allow the vehicle specific plug to be installed.

2-Plug units are designed for brake controls that have a wiring port built into the back of the unit. Simply plug the brake control end of the wiring harness into the back of the brake control and the vehicle end into the automobile's port. Brake controls that utilize the 2-plug style of wiring harness will be identified with the Plug & Play logo.



<b>NEW!</b> 3014** 3014-P 3014-S 20276†	 3015** 3015-P 3015-S* 20264*† 22284†	 3016** 3016-P 3016-S 20275† 22295†	<b>NEW!</b> 3017** 3017-P 3017-S	 3020** 3020-P 20261*† 22281†	 3021** 3021-P 3021-S 20273*† 22293†
 3023** 3023-P 3023-S 30234-P 30235 30235-P 20277†	 3025** 3025-P 3025-S 20263*† 22283†	 3026** 3026-P 3026-S 20269*† 22289†	 3032** 3032-P 20271† 22291†	 3034** 3034-P 3034-S 20270† 22290†	 3035** 3035-P 3035-S* 20260*† 22280†
 3036** 3036-P 3036-S 20272*† 22292†	 3040** 3040-P 3040-S 20265† 22285†	 3045** 3045-P 3045-S 20274† 22294†	 3050** 3050-P 3050-S 20266† 22286†	 3065** 3065-P 3065-S 20267*† 22287†	 3070** 3070-P 3070-S 20268† 22288†

\* Clam and also available in bulk 12-pack. (Ex: 3015-S-012) \*\* Bulk 20-pack. † = Available while supplies last.

- BP1** - Under or behind dash, to the left or right of the emergency brake pedal.
- BP2** - Under or behind dash to the left of the steering column and brake pedal.
- BP3** - Under or behind dash to the right of the steering column and brake pedal.
- BP4** - Kick panel area, on the Driver's side.
- BP5** - Under or behind dash, behind the center console.
- BP6** - Under or behind dash on the passenger side, near glovebox.
- BP7** - Centered behind dash between the steering column and the radio.
- BP8** - Under or behind dash to the right of the steering column and brake pedal. Also includes 7-Way adapter kit located at the rear center behind the bumper. This unit complies with all applicable California Regulations.
- BP9** - Includes 7-Way adapter kit located at the rear center behind the bumper. This unit complies with all applicable California Regulations.

**VEHICLE SPECIFIC BRAKE CONTROL WIRING HARNESS POSITION**



† = Available while supply lasts.

# BRAKE CONTROL WIRING HARNESSES APPLICATION GUIDE



1-PLUG CLAM    1-PLUG CLAM    2-PLUG CLAM    2-PLUG CLAM    2-PLUG BULK

Model	Year	PDS	Part No.	Part No.	Part No.	Part No.	Part No.
<b>FORD</b>							
Bronco Full Size	94-96	BP3	20260†	3035-S	22280†	3035-P	3035
E-150 Econoline Van Full Size, All Models	92-08	BP3	20260†	3035-S	22280†	3035-P	3035
E-150 Econoline Van Full Size, All Models	09-14	BP7	20270†	3034-S	22290†	3034-P	3034
E-250 Econoline Van Full Size, All Models	92-08	BP3	20260†	3035-S	22280†	3035-P	3035
E-250 Econoline Van Full Size, All Models	09-14	BP7	20270†	3034-S	22290†	3034-P	3034
E-350 Econoline Van Full Size, All Models	92-08	BP3	20260†	3035-S	22280†	3035-P	3035
E-350 Econoline Van Full Size, All Models	09-14	BP7	20270†	3034-S	22290†	3034-P	3034
E-350 Econoline Van RV Cutaway w/Factory Tow Prep Plug	92-08	BP3	20260†	3035-S	22280†	3035-P	3035
E-350 Econoline Van RV Cutaway w/Factory Tow Prep Plug	09-11	BP7	20270†	3034-S	22290†	3034-P	3034
E-450 Econoline Van RV Cutaway w/Factory Tow Prep Plug	92-08	BP3	20260†	3035-S	22280†	3035-P	3035
E-450 Econoline Van RV Cutaway w/Factory Tow Prep Plug	09-11	BP7	20270†	3034-S	22290†	3034-P	3034
Excursion	00-05	BP3	20260†	3035-S	22280†	3035-P	3035
Expedition	97-12	BP3	20260†	3035-S	22280†	3035-P	3035
Expedition	13-15	BP5	20270†	3034-S	22290†	3034-P	3034
Explorer w/Factory Tow Package	02-05	BP6	20260†	3035-S	22280†	3035-P	3035
Explorer w/Factory Tow Package	06-10	BP2	20260†	3035-S	22280†	3035-P	3035
Explorer w/Factory Tow Package	11-15	BP2	20260†	3035-S	22280†	3035-P	3035
Explorer Sport Trac w/Factory Tow Package	07-10	BP2	20260†	3035-S	22280†	3035-P	3035
F-150	94-96	BP3	20260†	3035-S	22280†	3035-P	3035
F-150 Flareside	04-08	BP3	20260†	3035-S	22280†	3035-P	3035
F-150 Flareside	09-15	BP3	20272†	3036-S	22292†	3036-P	3036
F-150 Styleside	04-08	BP3	20260†	3035-S	22280†	3035-P	3035
F-150 Styleside	09-15	BP3	20272†	3036-S	22292†	3036-P	3036
F-150 Light Duty Flareside	97-03	BP3	20260†	3035-S	22280†	3035-P	3035
F-150 Light Duty Styleside	97-03	BP3	20260†	3035-S	22280†	3035-P	3035
F-150 Light Duty Heritage Flareside	04	BP3	20260†	3035-S	22280†	3035-P	3035
F-150 Light Duty Heritage Styleside	04	BP3	20260†	3035-S	22280†	3035-P	3035
F-150 SuperCrew	00-03	BP3	20260†	3035-S	22280†	3035-P	3035
F-150 SuperCrew	04-08	BP3	20260†	3035-S	22280†	3035-P	3035
F-150 SuperCrew w/5.5 & 6.5 ft. Beds	09-15	BP3	20272†	3036-S	22292†	3036-P	3036
F-250	94-96	BP3	20260†	3035-S	22280†	3035-P	3035
F-250 Heavy Duty	97	BP3	20260†	3035-S	22280†	3035-P	3035
F-250 Light Duty Styleside	97-99	BP3	20260†	3035-S	22280†	3035-P	3035
F-250 Super Duty	99-04	BP3	20260†	3035-S	22280†	3035-P	3035
F-250 Super Duty	05-07	BP5	20267†	3065-S	22287†	3065-P	3065
F-250 Super Duty	08-15	BP3	20270†	3034-S	22290†	3034-P	3034
F-350	94-96	BP3	20260†	3035-S	22280†	3035-P	3035
F-350 Heavy Duty	97	BP3	20260†	3035-S	22280†	3035-P	3035
F-350 Super Duty	99-04	BP3	20260†	3035-S	22280†	3035-P	3035
F-350 Super Duty	05-07	BP5	20267†	3065-S	22287†	3065-P	3065
F-350 Super Duty	08-15	BP3	20270†	3034-S	22290†	3034-P	3034
F-350 Super Duty Cab & Chassis	05-07	BP5	20267†	3065-S	22287†	3065-P	3065
F-350 Super Duty Cab & Chassis	08-15	BP3	20270†	3034-S	22290†	3034-P	3034
F-450 Super Duty	08-14	BP3	20270†	3034-S	22290†	3034-P	3034
F-450 Super Duty Cab & Chassis	99-04	BP3	20260†	3035-S	22280†	3035-P	3035
F-450 Super Duty Cab & Chassis	05-07	BP5	20267†	3065-S	22287†	3065-P	3065
F-450 Super Duty Cab & Chassis	08-15	BP3	20270†	3034-S	22290†	3034-P	3034
F-550 Super Duty Cab & Chassis	99-04	BP3	20260†	3035-S	22280†	3035-P	3035
F-550 Super Duty Cab & Chassis	05-07	BP5	20267†	3065-S	22287†	3065-P	3065
F-550 Super Duty Cab & Chassis	08-15	BP3	20270†	3034-S	22290†	3034-P	3034
Flex w/Factory Tow Package	09-11	BP2	20260†	3035-S	22280†	3035-P	3035
Flex w/Factory Tow Package	12-13	BP3	20272†	3036-S	22292†	3036-P	3036
Flex w/Factory Tow Package	14-15	BP5	20270†	3034-S	22290†	3034-P	3034
Windstar w/Factory Tow Package	95-03	BP3	20260†	3035-S	22280†	3035-P	3035

† = Available while supply lasts.