

StepAbove™

INSTALLATION INSTRUCTIONS



THE NEXT GENERATION OF RV STEPS FOR STABLE AND SECURE FOOTING

NOTE: MORryde is responsible for the design and manufacturing of our parts; we are not responsible for the structure it is mounted to. Improper installation may cause property damage or personal injury. MORryde cannot be liable for property damage or injury caused by incorrect mounting or incorrect use during travel or otherwise. It is up to the installer to verify the safety of any installation method or hardware that is not provided by or recommended by MORryde.

STEP 1 Remove step transition strip between existing door threshold and floor.

STEP 2 Place StepAbove™ inside the center of door opening.

STEP 3 Lift StepAbove™ and lock into place. Ensure that the latches have engaged with thin flange of the door jamb.

- Some doors may require notching of interior wood or trim-work.

STEP 4 Measure 15/16" from inside of threshold to front of StepAbove™ hinge plate. This will ensure your new StepAbove™ threshold fits snugly over your existing threshold.

STEP 5 Make sure StepAbove™ is in the center of the door opening – The distance between the inside lip on the door jamb and the outside edge of the step must be 1/8" clearance on each side.

STEP 6 Mount (2) outermost screws on StepAbove™ hinge plate to hold in place.

STEP 7 Lower StepAbove™ and make sure they operate smoothly and that the StepAbove™ is aligned correctly.

STEP 8 Raise StepAbove™ up into the locked position and secure the hinge plate with remaining screws.

STEP 9 Lower your newly installed StepAbove™ entry steps and enjoy a safe and secure entry and exit!

- Note that the legs are adjustable and may need to be retracted in order to fit inside the door opening

