



## INSTALLATION GUIDE





# ASSEMBLY GUIDE FOR MOAB SINGLE BAR


DISCOVER THE WILD


Enjoy the Adventure

EXCHANGEABLE AND ADJUSTABLE PARTS




## **Pieces**





















SOCKET HEAD BOLT HEXAGONAL

M8X25







REGULAR PLAIN WASHER

M8




SAFETY NUTS M8





THICKER PLAIN WASHER M8






HEXAGONA HEAD BOLTS M8








BED RAIL CLAMPS M8










TRAIL RAIL CLAMPS M8







- Place pieces **A** and **B** on the bed rail of the truck.
- -Use two pieces **#6** to secure each side on the inside of the bed rail, use two hexagonal head bolts M8X25 and two regular plain washers for each of them.















- Place pieces **A** and **B** on the bed rail of the truck.





-Use two pieces **#7** to secure each side on the inside of the bed rail, use two hexagonal head bolts **M8X25** and two regular plain washers for each of them.



































-Place pieces **D** on pieces **A** and **B** as shown in the images, on the side that has the two round holes marked in the image



































20<sup>1</sup>

HEIGHT OPTION





Following the last step, place the main cross bars (piece **E**) symmetrically with the elbow joints, making sure they both align. Secure with 4 bolts with the corresponding fixing points on piece **C** shown in the images.





























At last, install both pieces **H** in the corresponding holes marked in the images.



















