

PM-30MV Kit

Saddle Modifications



1

Cut or Grind the saddle



2

Place the ball screw in to test clearance



3

On some PM-30 mills you will have to make room for the Y axis ball nut.