

Blinds4You

Measuring Guide for Roman blinds in a Square Angled/ Box Bay window

With Blinds4You, measuring for your beautiful new blind is easy. Just follow this step-by-step guide, taking care to double check as you go and look out for some handy tips to help you save time too. Below is a handy guide for measuring for Roman blinds in a Square Angled/ Box Bay window.


This guide works for:

- Roman blinds

Step 1 – Measuring the width

Roman blinds are the professional's choice for a Square Angled/Box Bay window.

Measure the width of side blinds from recess edge into the corner then deduct the bracket allowance of 45mm. Measure from corner to corner and deduct two bracket (90mm) allowances for the front blind. Order all three blinds as Exact fitting.



Step 2 – Measuring the drop

The drop can be measured as normal – again in three places. Be aware of how you are fitting the blinds so you know where the top is to measure down from.

Note that the headrail is included in the drop measurements. You will need 30mm flat space to mount brackets securely.

Once you have noted your measurements, enter the sizes into www.blinds4you.co.uk/collections/roman-blinds and choose the Exact fitting option. We will make your new blind to your sizes without deductions and send them out to you ready to fit.