

C.C.Rider Seat

Installation Instruction

Passenger Sissy Bar Uprights Backrest Pad

WARNING

Rider and passenger safety depend upon the correct installation of this kit. Improper installation of this kit could result in death or serious injury.

NOTE

When performing the following installation procedures, avoid scratching painted surfaces (fender, tank, etc.) with tools or metal seat tabs.

INSTALLATION

1. If necessary, cut the plastic rain seal away from the three pre-cut screw holes (D) in the backrest pad (1) to prevent the plastic from catching in the threads.
 2. On a vehicle with Detachable Sissy Bar Upright installed for Passenger Sissy Bar Upright (A):
 - a. Insert three long spacers (3) into pre-cut holes (D) in the backrest pad (1).
 - b. Position backrest (1) against sissy bar upright (A).
 3. On a vehicle with Detachable Sissy Bar Upright installed for Short Passenger Sissy Bar Upright (B):
 - a. Position backrest (1) against sissy bar upright (B).
 - b. Insert three long spacers (3) through the slots in sissy bar tabs (C) into pre-cut holes (D) in the backrest pad (1).
 4. Place the mounting bracket (2) against the spacers, so that the holes of the mounting bracket align with the spacers.
- *To avoid misalignment and cross-threading of the screws, start all three screws into the backrest before tightening.
5. Insert a screw (4) from the kit through one of the spacers, and carefully thread it 4-5 turns into the mating hole in the backrest pad. Repeat with the other two screws.
- *DO NOT tighten a screw until all three screws have been started.
- *Spacers must seat squarely against the mounting bracket.
6. Once all three screws have been carefully started into the three holes of the backrest pad, tighten the screws. Tighten.

