

Wiring

Power Connector

Black	Connect to the Ground (chassis of the car)
Red	Connect to the Power of the car (until 30 Volts). Must be install with 5 Amps Fuse.

I/O Pins Connector

Pink	Positive of the EGT Sensor
Orange	Negative of the EGT Sensor
Grey	External Input For Changing Boost Maps
Brown	Rpm Input Signal
Green/Brown	Customizing 12 Volts 1 Amps Output
Cyan	Solenoid Output
Green	Vehicle Speed Input Signal
White/Red	External Input For Safe Mode(Off Map)
Yellow	Afr Analog Input
Red/Yellow	External Analog Input

Solenoid Connector(Mac)

Positive pin	Is Going to Boost Controller (Connected to I/O Pins Connector)
Negative pin	Connect to the Ground (chassis of the car)

CanBus Module

Yellow	CanH (Pin 6 of OBD)
Green	CanL (Pin 14 of OBD)
Orange	12v (Pin 16 of OBD)
Grey	K-Line (Pin 7 of OBD)
Brown	Ground (Pin 4 of OBD)