

Inspiredwall™

Your Inspiration Realized.

Installing Your Inspiredwall™ Recommended Tools and Adhesive

Checklist of Needed Tools

- Personal protective equipment
- Level and chalk line
- Tape measure and pencil
- Electric miter saw (recommended—can typically be rented at your local big box home improvement store) or miter box and hand saw
- Caulking gun and a high strength construction adhesive (see below).

Optional Tools (Depending on Installation)

- Handsaw (for cutting out plugs and switch plates)
- Ladder

Adhesive

We've experienced good results with **Loctite® PL® PREMIUM FAST GRAB** Construction Adhesive (#1417170) when applying your **Inspiredwall** panels to drywall. You can find this product at just about home improvement store in your area. There are undoubtedly other construction adhesives that will work for this kind of installation. The key is finding one that is ideally suited for vertical installations. You'll need approximately 1-10oz. tube of construction adhesive per 20 square feet of paneling.

NOTE: We that have no relationship with Loctite® or the Henkel Corporation. We provide this information only as a starting point. Your own installation might require a different adhesive based on the composition of your receiving wall. Whatever adhesive you choose, follow the label instructions.