



METALLBUDE



Shower Tray SHEA

Instructions // Shower Tray SHEA

1. Mix the special adhesive according to the instructions.
2. **Attention:** For a secure hold, clean and degrease the back of shower tray SHEA, as well as the desired wall surface thoroughly beforehand!
3. Apply the special adhesive to the areas marked gray in the illustration and remove the film from the adhesive strips.



4. Position the back of the shower tray (with the adhesive surface) on the desired location and press it against the wall for at least 10 seconds.
5. Wait at least 4 hours before the shower tray is in contact with moisture to allow the special adhesive to fully harden.

Done! Have fun with SHEA!