



METALLBUDE



Assembly instructions | VINIA



4 x Countersunk screws



4 x Dowels

1. Mark the drill holes for VINIA at the desired wall position
Our tip: Position VINIA on the wall and press the supplied countersunk head screw into the drill holes to set markings for the drill bit.

Make sure that you press firmly and center the mark in the hole.

2. Drill holes in the marked positions.

At least 6 cm deep

Drill diameter: 6 mm

3. Insert the dowel into the hole and fasten VINIA with the countersunk screws.

Our tip: VINIA is best installed by two people.

Fertig! Viel Spaß mit VINIA