



METALLBUDE



Wine Rack VINIA



Instructions // Wine rack VINIA



4 x countersunk screws



4 x dowels

1. Mark the drill holes for VINIA at the desired wall position.

Our tip: Position VINIA on the wall and press the supplied countersunk screw into the holes to make marks for the drill. Make sure you press firmly and center the mark in the hole.

2. Drill holes in the marked positions.

At least 6 cm deep

Drill diameter: 6 mm

3. Insert the dowel into the hole and fix VINIA with the countersunk screws.

Our tip: VINIA assembly works best with two people.

Done! Have fun with VINIA!