- 1. Carefully open the carton and remove all pieces.
- 2. Lay the 3 cushion pieces down on a clean flat surface.
- 3. Remove the bolts for the hinges on the leg and head sections and line up the hinges.
- 4. Insert the bolt you removed through the hinges and start all four by hand before fully tightening. If you want to remove the plastic from under the hinges, this is the best time to do so by removing the bolts holding the hinges on the head and leg sections, remove the plastic and replace them.
- 5. Once all 4 hinges are connected, remove the 4 remaining bolts that are left in the middle section. Note, 2 of these are longer and will need to go back in the same place.
- 6. Turn the frame upside down on the cushion pieces and line up the holes in the frame with the holes in the middle section of the bed.
- 7. Put the 4 bolts in tightening them by hand before fully tightening them.
- 8. Remove the 4 poles and the hollow stainless tube from the wrapping.
- 9. Get the 2 T-Shaped brackets and connect them to the frame where you can see 2 bolts, one on either side. The hollow silver stainless tube will go between the 2 T-Shaped brackets.
- 10. The poles connect to the brackets in the back of the leg and back sections, do this by removing the longer nut and bolt from the pole, slide the pole through the hole in the T-Shaped bracket and to the connection bracket, connect it using the nut and bolt that you removed earlier. Repeat this process until all 4 are connected and the nuts and bolts have been tightened (these do not need to be too tight or the section will not move as freely.)
- 11. Using the screws supplied, fix the large steel plate that is connected to the control box to the underside of the bed, this can go either way. Connect the height motor in the slot in the control box.
- 12. Screw the D bracket to one side of the bed where you would like the hand control to hang, it does not need to hang out too much and if you put it in the wrong place it is easily moved later on.
- 13. After screwing the legs into the bottom of the frame, carefully put the bed upright, connect the power cord and the hand control.
- 14. Fit the arms if required and your bed is ready to use.

Below are images of how the pole sections should look when assembled.



Please contact your place of purchase if you have any issues with assembly or with using the bed.