



Tips:

Test fit each part prior to gluing
Recommend PVA (wood) glue or Super Glue

- Test fit ruined arches before gluing!
- Smaller ruined arches can be placed as desired on the terrain by gluing them to the bottom

