



Tips:

Test fit each part prior to gluing
Recommend PVA (wood) glue or Super Glue

- Glue window backs and window frames to walls before assembling walls
- Slot counter top into window before gluing window back on wall

