

Instructions for all Firm Tag options



Installation

1. Turn OFF power on power source (Recommended)
2. Slide and press the C14 or C20 Firm fully onto the moulded plug
3. Firmly grip the plug and insert into the receptacle/outlet
4. Ensure the power cord's plug is fully inserted into the receptacle/outlet to prevent arcing
5. The only visible portion of the C14 or C20 Firm will be the removal tabs
6. Turn power ON

Removal

1. Turn power OFF on power source (Recommended)
2. Firmly grip power cord at plug and remove slowly/carefully (take care not to damage the outlet when removing the plug)
3. If the C14 or C20 Firm stays in the outlet, remove it using the removal tabs
4. Turn power ON