

readytec.com.au

Instructions for all Lockout Cap options





Installation

ReadyTec

- 1. Turn OFF power on power source (Recommended)
- 2. Press the C14 or C20 Lockout fully into the required outlet
- 3. Turn power ON

Removal

- 1. Turn power OFF on power source (Recommended)
- 2. Insert special non-conductive "T" bar removal tool and rotate clockwise and by pulling remove slowly/carefully
- 3. Turn power ON