



350Z Street Shark Rear Install

Tools Needed

- Angle grinder or die grinder with cutoff wheel (sawzall or reciprocating saw not recommended)
- Masking Tape
- Measuring Tape
- Marker
- Razor knife or sanding block



- 1) Remove bumper cover and stock bash bar

- 2) Install Street Shark Bash bar with provided hardware with eight M8x30mm bolts, measure from end of bar to side of vehicle on each side to ensure centered fitment



- 3) Start laying out for the bumper cover cut by measuring and marking $7 \frac{5}{8}$ " down from the far right ledge, $1 \frac{3}{4}$ " down from the corner marker light, and 1" down from the license plate emboss
- 4) Connect your marks with the bottom edge of a long strip of masking tape. The smoother you lay out your tape the better the end cut will look



5) Carefully cut along lower edge of tape



6) Clean up edge with razor knife or sanding block



7) Reinstall bumper cover and enjoy your perfectly fit Street Shark Rear bash bar!