



Power Pack

Premium quality additive for hot water extraction cleaning

Features & Benefits

- Excellent cleaning power. Penetrates and removes a wide range of soils without spotting.
- Very high levels of water softeners in Power Pack eliminates calcium build up in water up to 200ppm hardness. Protects pumps and equipment in even the hardest waters.
- Power pack is formulated with free rinsing detergent that reduce drying time.
- The free rinsing detergents in Power Pack produce a residue free finish. Many other products leave a residue which attracts dirt and soil.
- Power Pack contains an inbuilt re-odouriser that leaves treated areas smelling fresh and clean.
- Power Pack is made in accordance to Australian Standard AS/NZS 3733: 1995. Textile floor coverings – Cleaning maintenance or residential and commercial carpeting. Completely safe product. Will not damage wool or synthetic fibres even in its undiluted form.
- Safe on all materials. Power Pack contains inhibitors which protect steel, aluminium, brass, bronze and most other metals used in door edging, hinges, borders to wooden or tiled floors.

Use Directions

Power Pack can be used to clean carpets and upholstery by adding it directly to the detergent tank of the machine or by the pre-spray method.

Be careful when treating carpet with jute backing. If colour-fastness needs to be tested either on carpet or upholstery, do so in an inconspicuous area.

Direct addition to detergent tank

Dry vacuum the area thoroughly.

Use 100mL of Power Pack for each 10 litres of water in the detergent tank. Warm water at 50-80°C in the detergent tank gives the best results.

Carpets that have previously been shampooed may cause foaming in the recovery tank. Antifoam C should be used.

Page **1** of **2**





Product Information Sheet

Pre-Spray Method

Dry vacuum the area thoroughly.

Add one litre of Power Pack to 10 litres of water. Spray this solution onto the area to be cleaned. Do not spray an area greater than 40 square meters at a time. Do not allow the solution to dry out. Extract the treated area using clean, warm water.

10 litres of the above solution should treat 40-80 square metres of carpet, depending on the degree of soiling.

Truck Mounted

A stock solution comprising 5 litres of Power Pack and 20 litres of water gives the easiest control of metering.

Safety Information

Refer to our safety data sheet (SDS) for more information or consult your Chemform representative for further assistance.

Packages

2x5L cartons and 20L drums



Page **2** of **2**