



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. Install the glass shade (4) into the frame (5) and secure with the glass clip (7).
4. Install the screws (6) into the frame (5) and the bobesche (3) until hand tight.
5. Install the cylinder nut (1) onto the cover plate (2).
6. Refer to the additional installation instructions included with the product for wiring and installation.
7. Restore power to the installation point and retain this sheet for future reference.