

Mini Instruction for Resin Art

1. Ensure that the workplace is a well-ventilated area.
2. Wear Disposable Respirator Mask if need.
3. Wear Finger Cot or Disposable Glovers first.

Below we use 20ml resin for example.

4. Open Part A resin bottle, pour 10ml into Measuring Cup. Then pour into Disposable Glue Cup, you can use Stirring Sticks.
5. Open Part B resin bottle, pour 10ml into New Measuring Cup (Don't use above one!). Then pour into above Disposable Glue Cup, you can use new Stirring Sticks.
6. Measure equally and accurately by volume, not weight. Adding too much of either the resin or the hardener will alter the chemical reaction and your resin will not cure properly.
7. Slowly stir your equally measured amounts of resin and hardener together for at least 3 minutes. Not stirring properly will result in a sticky resin that will never cure.
8. Scrape the bottom and sides of your mixing cup as you stir to ensure the entire mixture catalyzes and that there is no remaining unmixed resin or hardener stuck to the sides that may prevent a proper cure.
9. You can use Disposable Alcohol Pads to clean if needed.

10. Wait 10-15 minutes.
11. Now you can add Resin Dye, Glitter, Gold leaf and Sequins into resin. Stir if needed.
12. Then you can pour resin into moulds.
13. For small mould, you can use Plastic Dropper.
14. Allow 48 hours to dry. (Don't touch during these time otherwise you will leave fingerprint on it.)
15. Take out cured piece out of mould carefully.
16. Using Sanding Strip if needed.