

## COMFORT EDGE INSTRUCTIONS



1. Center Comfort Edge to underside of worksurface.
2. Using the pre-drilled holes, fasten Comfort Edge to underside of worksurface using the provided #10 x 3/4 screws.

