



NEXposture™

DESK/TABLE CASTERS INSTRUCTIONS

ASSEMBLE LEGS TO WORKSURFACE

1. On the underside of laminated surface, center leg frame front-to-back and near side edge.
2. Using the pre-drilled holes, fasten leg frame to underside of worksurface using the provided #10 x 3/4 screws.
3. Repeat for remaining leg frame.

