



Official Licensed Product



MERCEDES-EQ  
FORMULA E TEAM

# Championship Edition Fender Assembly Instructions

# Front Fender

## Parts Included:







Front Fender		1 x
Small Hex Socket Screw		1 x
Spring Washer		1 x

## Tools Required:

3mm hex key

# Rear Fender

## Parts Included:

Rear Fender		1 x
Large Hex Socket Screw		1 x
Screws		2 x
Flat Washers		4 x
Nut		1 x
Bracket		1 x

## Tools Required:

4mm hex key

8mm Spanner

Phillips Head Screwdriver

# Front Fender Assembly

- 1/ Between the front fork, attach the small hex socket screw and spring washer. Tighten using a 3mm hex key.



# Rear Fender Assembly

- 1/ Insert the bracket into the rear fender as shown below. Ensure the holes line up. Secure with two screws and two washers utilising a phillips head screwdriver.



2/ Use the large hex socket screw and a washer to attach the rear fender to the bike as shown below.



4/ On the underside, use a 8mm spanner to attach and secure a nut and washer to the large hex socket screw. Ensure it is done up tight.



3/ Tighten completely using a 4mm hex key.





# Disclaimer

Please note your bike warranty does not cover incorrect assembly or installation of parts. To find a recommended service centre near you, please head to [nplusbikes.com](https://nplusbikes.com), or alternatively a local reputable bike shop.

## Contact us

Support


US: +1 833-631-0071


UK/EU: +44 808 304 8296

AU: +61 1800 319 714

EMAIL [support@nplusbikes.com](mailto:support@nplusbikes.com)

## Get social

 @nplusbikes\_

 @nplusbikes

Official Licensed Product



MERCEDES-EQ  
FORMULA E TEAM