

--- 7" & 10" BRACED BED BRACKET - INSTRUCTION GUIDE ---



WHAT'S IN THE BOX:

- 2 X BED BRACKETS
- 6 X COACH SCREWS
- 6 X BOLTS
- 6 X NUTS
- 12 X WASHERS

HOW TO ASSEMBLE:

1. Turn ensemble base onto side and unscrew two end castors.
2. Hold brackets against bed and refit the castor through the slot in the bracket temporarily.
3. Place ensemble base into the normal position on the floor to establish position of bracket in relation to bedhead (we recommend placing the bedhead on the floor rather than having it suspended as our brackets are not designed to support the full weight of the bed head). Make small markings in pencil where drill holes will be required for mounting (this may already be done by your bedding manufacturer).
4. Remove castor and bracket from ensemble to now mount bracket to bedhead.
5. Drill two holes in bedhead where you had marked out previously (this may already be done by your bedding manufacturer). Screw 2x bolts with washers on each bracket with nuts on reverse to securely hold bedhead in place. Tighten till firm.
Note: as bedheads can vary in thickness, the bolts supplied may not be the correct length. Different length bolts are available from your local hardware store.
6. You can now refit the castor back through the bracket into the base. For extra support, screw 2x screws into each bracket's drill holes.
7. Enjoy a good night's sleep after successfully fitting your bedhead to ensemble.