

## **WORX RACING INTAKE GRATE**

**PART # - WR221** 

MODELS: SEADOO RXT 04-09, GTX 4-TEC, GTX S/C, GTX DI 02+

## INSTALLATION INSTRUCTIONS

## IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

**Tools:** 13mm socket wrench

10mm socket wrench

Tube of Marine silicone sealant

Parts Supplied: 1 x WORX WR221 Intake Grate

- 1- Remove stock intake grate and clean hull of old silicone and residue
- 2- Apply Marine silicone sealant around mounting holes on WORX intake grate and around rear mount surfaces and edges of intake grate.
- 3- Fit WORX intake grate into position using OEM bolts
- 4- Wipe away excess sealant with cloth. Allow 24 hours for sealant to cure before riding
- 5- Regularly check that all bolts are tight on your intake grate.

Thank you for purchasing **Worx Racing components** products. We firmly believe that **Worx Racing Components** products are among the finest watercraft parts available. A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products please contact us at the numbers listed on page one or through your local **Worx** dealer.

10B 354 Brisbane Rd Arundel QLD 4214 Phone: +61 7 5563 1031 www.worx.com.au / info@worx.com.au