



## WORX RACING RIDE PLATE

**PART # - WR315**

**MODELS: YAMAHA SUPERJET 96-07 FREERIDE**

---

### **INSTALLATION INSTRUCTIONS**

**IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION**

**Parts Supplied:**

**1 x WORX WR315 Ride Plate**

- 1- Put ski on a flat surface. Roll onto left side. Remove OEM Ride Plate, wipe clean any old silicone and residue from hull.
- 2- Apply a small amount of Marine silicone sealant to both mounting surfaces of your new **WORX** Ride Plate and around mounting holes.
- 3- Fit **WORX** ride plate into position using OEM bolts.
- 4- Wipe off excess sealant with a damp cloth. Allow 24 hours minimum for sealant to cure before riding.
- 5- Regularly check all bolts are tight on your ride plate.

Thank you for purchasing **WORX Racing components** products. We firmly believe that **WORX Racing Components** products are among the finest watercraft parts available. A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products please contact us at the numbers listed on page one or through your local **WORX** dealer.

10B 354 Brisbane Rd Arundel QLD 4214 Phone: +61 7 5563 1031

[www.worx.com.au](http://www.worx.com.au) / [info@worx.com.au](mailto:info@worx.com.au)

---