



## WORX RACING SPONSONS KIT

**PART # - WR557**

**MODELS: YAMAHA VX110, DELUXE, CRUISER 05-14/ V1, V1 SPORT 15+**

---

### **INSTALLATION INSTRUCTIONS**

Parts Supplied:        2 x **WORX Racing** adjustable sponson paddles  
                                 2 x **WORX Racing** Backing rails  
                                 10 x M8 x 40 Button head bolts  
                                 10 x 8mm x 19mm Flat washers

**IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION**

- 1- Make sure ski is secure and on a flat surface. Remove lanyard.
- 2- Remove OEM Sponson paddles from hull. Clean away old silicone and residue from hull.
- 3- Run a bead of Marine silicone sealant around 5 mounting holes on hull and a bead along both sides of the Sponson Backing rail.
- 4- Select desired hole mounts and fit bolts thru Sponson paddle and Backing rail then start threads into hull. Tighten bolts to pull up sponson firm to hull. Do Not overtighten!
- 5- Clean away excess sealant

NOTE: Sponsons mounted in lowest position will have most aggressive turning. Raising sponsons will make sponsons less aggressive. Regularly check sponson bolts.



Thank you for purchasing **Worx Racing components** products. We firmly believe that **Worx Racing Components** products are among the finest watercraft parts available. A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products please contact us at the numbers listed on page one or through your local **Worx** dealer.

10B 354 Brisbane Rd Arundel QLD 4214 Phone: +61 7 5563 1031

[www.worx.com.au](http://www.worx.com.au) / [info@worx.com.au](mailto:info@worx.com.au)

---