DUMOND® PAINT REMOVAL TEST KIT INSTRUCTIONS

Full Product TDS Sheets for Peel Away 1, Smart Strip Advanced, and Smart Strip PRO are available at: www.dumondglobal.com.

Before opening and applying any products, put on rubber gloves included in the kit.

- 1. Apply all 3 products in the kit (Smart Strip® Advanced, Smart Strip® Pro, and Peel Away® 1) to the substrate in a 5" x 5" test area using the provided brushes. Apply at the appropriate specified label thickness (min 1/8 " to 1/4" where multiple coats of paint need to be removed). Use masking tape (not included) to separate the samples in a grid pattern if necessary to avoid overlapping of products.
- 2. Apply a pre-cut piece of Dumond® Laminated Paper (included) to each of the samples and lightly smooth over the patch area, printed side out. Tape down all edges to the substrate. Dumond® Laminated Paper decreases the dwell-time and prevents premature drying. It is normally sold separately.
- 3. Allow between 1-24 hours of dwell time before checking results. Take note of the dwell time and temperature during the test, as well as any humidity or weather conditions which may have affected the test.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. LEAD IS TOXIC. Contact the National Lead Information Hotline at 1-800-424-LEAD or log onto www.epa.gov/lead for more information.

4. Put the gloves back on before product removal. After appropriate dwell times, using enclosed plastic scrapper, gently scrape under the remover and Dumond Laminated Paper starting at a corner. Carefully lift the paper, remover, and paint coatings in one continuous motion. Once removed, immediately scrub the surface using the included pad and water, high pressure hose, or pressure washer. Surface should now be clean and free of paint film.

Important Note: After using Peel Away® 1, surface neutralization is necessary following the paint removal process. Follow the instructions on the Citri-Lize® Neutralizer included in your kit. Neutralization is only necessary on the Peel Away® 1 test patch.

Always wear gloves when opening, closing, applying, or removing any of products included with this test kit.

Based on these test results, you can now consult your local Dumond® paint removal dealer and order the correct product for your specific project. Visit www.dumondglobal.com to locate a dealer near you, or shop online.

Dumond®
253 S. Bailey Road
Downingtown, PA 19335
(610) 383-6061
www.dumondglobal.com
info@dumondglobal.com

