



THUREN FABRICATION 2009-2022 RAM 1500 REAR SWAY BAR LINKS

These instructions are applicable to the following Trucks:

- 2009-2022 Ram 1500 with rear coil spring suspension

Applicable part number:

TF-SBLKIT-130

Tools Required:

Standard Socket / Wrench tool kit
Drill with 1/2" drill bit (as necessary)

1. Pre-assembly

- Park on level ground
- No need to remove the wheels or jack your truck up
- Remove both OEM Sway Bar Links.
 - The tip of the bolt head has a allen socket to assist with removal. (image 1)



WARNING

Test fit the supplied 1/2" bolts in the frame and Sway Bar mount holes. Each bolt should effortlessly slide through mount hole. If it's a tight fit, use your drill and 1/2" drill bit to clean up the holes and open them up.

2. Installation

- Mount Sway Bar Links on outside of Frame and Sway Bar with the Zerk fittings facing forward and pointed upward.
- Install the Stainless Steel Crush Sleeve with the flat face against the frame and against the Sway Bar.
- Bolts should be installed with bolt head on the outside against Center Ball.
- Final torque on all hardware is 110 Ft/Lbs.
- Grease all four Zerks with high quality synthetic grease and enjoy the ride!



Image 1

